

The Kustom Kaddy

Switch Housing Mount Kit for Goldwings, Harleys and other applications

Mounting Instructions

1. Remove the two existing socket head bolts from switch housing (clutch or brake side) on handlebar. The large round hole in the triangular plate should be the highest position pointing towards the center of the bike.

2. **Use M6x44 socket head bolts in metric bikes or US standard bolts in American standard bikes.** Screws can be identified as metric or standard by comparing threads from the removed screws to the screws included in kit.

Insert supplied head bolts (6,7,or,8) through the triangular mounting plate (4) through the 5/8 inch spacers(5) and insert into the switch housing making sure that the large hole is up. Do not over tighten.

3. Attach mounting stud (2) to mounting plate (4) with mounting stud bolt (1) and acorn nut (3). The oval end of the stud should be facing toward bolt head and rider. The oval end should be perpendicular to the ground with the bike in an upright riding position.

4. The cupholder is mounted by putting the large diameter of the keyhole over the mounting stud bolt and slide the cup down onto the groove in the mounting stud. The rubber may then be inserted into the large diameter of the keyhole, thus locking the cup on the mounting stud.

