



BOOMERANG FRAME COVERS 3911

WITH SCUFF PROTECTOR

FITS: FITS '01-UP GL1800

PART #	INCLUDED
903910	1 Left Frame Cover
	1 Right Frame Cover
	1 Hardware Kit Including The Following:
	6 M5 x .80 x 20mm Threads with 3mm Shoulder BSCS
	1 Anti-seize
	2 Alcohol Pads
	1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

IN ORDER TO PROTECT YOU AND OTHERS FROM POSSIBLE INJURY AND/OR PROPERTY DAMAGE OR LOSS, PLEASE PAY CLOSE ATTENTION TO ALL INSTRUCTIONS, WARNINGS, CAUTIONS AND ATTENTION NOTES REGARDING THE USE AND CARE OF THIS PRODUCT.

ATTENTION! This indication alerts you to the fact that ignoring the contents described herein may negatively affect product performance and functionality.

NOTE Cleaning the surface of the frame that the adhesive tape will adhere to is very important. Installation of this part should not be done if the surface temperature of the frame is below 60 degrees Fahrenheit.

ATTENTION! Be sure to use the supplied anti-seize on all threaded fasteners before installation. This will reduce galling and make future removal of the fasteners easier.

STRICTLY OBSERVE THE FOLLOWING GUIDELINES IN ORDER TO USE THE PRODUCT PROPERLY AND AVOID POTENTIALLY DANGEROUS ACCIDENTS.

PROCEDURE

STEP 1 Remove fasteners from stock swing arm pivot covers and remove the cover. (See PIC.1 and PIC.2.)

-cont.-



CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.

· Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.

· Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.

· Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



STEP 2 Remove the stock, gray plastic covers from each side of the frame. The top of each gray cover is secured by a black plastic insert, the bottom is secured by two sided tape. To remove the plastic insert, carefully extract the pin found in the center of the insert until it stops, then remove the entire insert from the frame. (See [PIC.3](#).)

STEP 3 Thoroughly clean surface of the frame with supplied alcohol pads where the covers will be installed.

STEP 4 Remove the backing from the adhesive pad installed on the upper end of the cover. Slip the cover into place, being careful to hold the upper end of the cover away from the frame as you maneuver it into position. Line up the holes in the frame cover with the holes in the frame and fasten with the screws provided. Place a dab of the enclosed anti-seize on each screw prior to installation. Thread them in fully, but do not tighten them at this time.

STEP 5 Once the screws are installed in the mounting holes, press the upper section of the cover into place and apply pressure for approximately 15 seconds to ensure proper adhesion.

STEP 6 Carefully tighten the mounting fasteners. Do not over tighten. (See [PIC.4](#).)

Ride On!

PIC.3



PIC.4

